

SURFACE MOUNTING:

STEP 1: Assembly 3 brackets parts using 4 pcs screws(PA4*8MM), refer to pictures A,B,C.

STEP 2: Make 6 holes (Φ6MM) on the ceiling according to the long bracket,

STEP 3: Place the plastic expansion ancor screws into holes on the ceiling, or use toggle bolts(not included).

STEP 4: Attach the brackets of step 1 on the ceiling with screws and to ancors.

STEP 5: Connect flex conduit through surface frame installation knock out and wire fixture according to wiring connections on Page 2.

STEP 6: Put the troffer into the brackets.

STEP 7: Attach the 4th bracket parts to close in the unit, make sure ceiling J-box is on side of the bracket not in the center, same side as driver box.

